


FELCO 2 Classic

Pruning shear - High performance - Classic model

Made in Switzerland by FELCO







- Reliable: comfortable, light, sturdy handles made of forged aluminium with a lifetime guarantee* / blade and riveted anvil blade made of high-quality hardened steel / clean, precise cut / all parts can be replaced
- Efficient: easy, durable cutting adjustment / wire cutting notch / sap groove
- · Ergonomic: hand protection is provided by the cushion-shock absorber / non-slip coating



Our recommendation (1 1: Recommended, 2 1: Strongly recommended, 3 1: Best fit)

Viticulture 📩	**
Arboriculture	**
Horticulture	**
Parks and Gardens	* *
Nursery	**
Small hand	**
Large hand	**
Left-handed T	**



The points of excellence



Forged aluminium handles guaranteed for life*

Lightweight, strong and sturdy thanks to special aluminium alloys and advanced precision forging methods perfectly mastered by FELCO.



Shock absorption system

FELCO's special cushion stops reduce impact at the end of a cut, protecting hand and wrist.



Precision adjustment system

FELCO's micrometric adjustment system guarantees an optimal adjustment of the cutting head throughout the life of the tool, and delivers a clean and precise cut every time.



Sap groove

The sap groove prevents the blade sticking when cutting "sappy" wood. It saves time and makes pruning easier by removing sap and debris after each cut.



Wire cutting notch

The blades of most FELCO pruning shears feature a notch that allows for the cutting of small wires without damaging the cutting edge.

Accessories







FELCO 910 <u>Holster</u> Leather - With belt loop and clip





Grease



FELCO 912 Holster Leather - With belt clip



FELCO 913 Holster In mock leather - With belt loop



FELCO 980 Maintenance product Spray



Spare parts

2/15 2/9 2/17 2/16 2/18 2/11 2/30 2/36	2/4 2/7 2/14 2/12 2/13 2/2	↓ _2/20		
	REF.	Designation	Composition	UCC bar code
0	2/30	Adjustment key	1x 2/30	
· •)	2/3	Blade	1x 2/3	7"83929 40001 3
	2/4	Anvil-blade with rivets	1x 2/4 + 4x 2/7	7 ^m 83929 ⁿ 40009 ⁿ 9
⊨ 0 ==)	2/90	Kit	1x 2/17 + 1x 2/16 + 1x 2/9 + 1x 2/8	7 83929 40014 3
	2/91	Kit	2x 2/11	7 83929 40018 1
V: V:	2/92	Kit	1x 2/15 + 1x 2/18 + 1x 2/14 + 1x 2/12 + 1x 2/13 + 1x 2/20	7"83929 40020 4
	2/93	Kit	4x 2/18 + 6x 2/20	7 83929 40021 1
0 -=	2/94	Kit	1x 2/9 + 1x 2/8	7"83929"40026"6
- The	2/1	Handle without blade	1x 2/1 + 3x 2/5B + 1x 2/19 + 1x 2/20 + 1x 2/10 + 1x 2/13 + 1x 2/12 + 1x 2/14 + 1x 2/35	



	2/2	Handle with anvil-blade	1x 2/2 + 1x 2/4 + 4x 2/7 + 1x 2/18 + 1x 2/36
	2/35	Plastic coating for blade handle	1x 2/35
~	2/36	Coating for anvil-blade handle	1x 2/36
	2/5B	Rivet for blade	1x 2/5B
Т	2/7	Rivet for anvil-blade	1x 2/7
(===	2/8	Bolt	1x 2/8
0	2/9	Nut	1x 2/9
5	2/10	Bush	1x 2/10
	2/11	White spring	1x 2/11
2	2/12	Thumb catch	1x 2/12
0	2/13	Spring for thumb catch	1x 2/13
¢.	2/14	Screw for thumb catch	1x 2/14
	2/15	Catch plate	1x 2/15
3 D	2/16	Locking segment	1x 2/16
\$ = =	2/17	Screw for locking segment	1x 2/17
þ	2/18	Cushion	1x 2/18
0	2/19	Edging	1x 2/19



2/20

Shock absorber

1x 2/20

Maintenance









Cleaning

It is advisable to clean your tool after each use.

If your tool is particularly dirty or subject to rusting after exposure to moisture, do not delay cleaning.

Oiling

After cleaning, it is advisable to oil the tool so as to protect it from corrosion. The oil will also unjam the tool.

Sharpening

It is advisable to sharpen your tool at least once a day, but if you feel that your tool is not cutting as well as usual, sharpen it right away!

Dismantling

It is advisable to dismantle your tool on a regular basis, but at the very latest when it appears to be jammed.



Replacement parts











Changing the blade

When the blade and the anvil-blade no longer cross, or when the blade is badly damaged, it is advisable to change it.

Regulate the working of the blade and anvil-blade by adjusting the tightening of the nut. The blade should rub against the anvil-blade over 2/3 of its length.

Changing the shock absorber

When the tool closes too abruptly during pruning, and the cushion is in good condition, the shock absorber should be changed.

Changing the cushion

When the tool closes too abruptly during pruning and the shock absorber is in good condition, the cushion must be changed.

Changing the thumb catch

When the thumb catch is damaged and loosens when used, even when the screw is readjusted, change it.

Changing the plastic coatings for handles

If the coatings are badly damaged, you can replace them.

Soak the coatings for 2 minutes in boiling water - recommended glue: Loctite 415.